

FUSE REPLACEMENT PROCEDURE

If the injector has no power, the fuse could be burnt out. Follow the procedure below to replace the fuse.

Tools Required:

- 3x16 Screwdriver
- 3x15 Screwdriver
- Fuse (1.6A/250V)



FACEPLATE PROGRAMMING PROCEDURE

- **STEP 1**
 - Unplug the power supply from from the injector
- **STEP 2**
 - Turn the Stroke Length Adjustment Knob to 0%
 - Remove the front **4** screws located in each corner of the front faceplate using a Philips screwdriver.
- **STEP 3**
 - Carefully remove faceplate, be careful of the knob's spring
 - Locate the fuse in the upper right corner.
 - Check the fuse using a multi meter.
 - If it is burnt out, replace with a **1.6A/250V** fuse.
 - There are replacement fuses located in the left-hand side panel box of the CCS Fertigation Machine, bottom right-hand corner.
- **STEP 4**
 - Re-assemble the injector faceplate, be careful to put the knob's spring back
 - Power up the injector.
- **STEP 5 – IF APPLICABLE**
 - If the injector is still not working or lighting up, contact our support team for additional assistance.

